
UM-SJTU JOINT INSTITUTE
PHYSICS LABORATORY
(VP141)

LABORATORY REPORT

EXERCISE 3

SIMPLE HARMONIC MOTION:
OSCILLATIONS IN MECHANICAL SYSTEMS

Name: Yihua Liu ID:518021910998 Group 9
Name: Guanghan Xi ID: 518021910778 Group 9

Date: August 2, 2019

1 Introduction

The main objective of this experiment is to study simple harmonic oscillations. We will learn how to calculate the spring constant and effective mass for two springs and the way to use the air track. We will explore the relationship between the period of the oscillation and the mass of the oscillator, the relationship between the oscillation period and its amplitude, and the relationship between its maximum speed and the amplitude.

The simple harmonic motion is the simplest periodic motion. The position of the oscillator is a sine or cosine function on time. Within the elastic limit of deformation, the relationship between the force F_x and the distance stretched or compressed x is described by Hooke's Law

$$F_x = kx \quad (1)$$

where k is the spring constant, examining the elasticity of a spring. In this experiment, we use the Jolly balance as the measurement device to find the spring constant. The force F_x is called the restoring force because the force tries to restore the spring back to the equilibrium, different from the elastic force in an opposite direction.




Figure 1. Mass-spring system.

As is shown in Figure 1, the block with mass M on the air track are attached to both two ends by two springs. Using the air track can eliminate the friction between the underside surface of the block and the ground. Initially, the block is set at equilibrium where we note the position coordinate $x = 0$. We will measure both the spring constants k_1 and k_2 of the two springs. Ignoring damping and the mass of the springs, by Newton's second law of dynamics, the motion of the block can be expressed by the equation

$$M \frac{d^2x}{dt^2} + (k_1 + k_2)x = 0 \quad (2)$$

Solving Eq. (2), we have

$$x(t) = A \cos(\omega t + \phi_0) \quad (3)$$

where $\omega_0 = \sqrt{(k_1 + k_2)/M}$ is the natural angular frequency of the motions, A is its amplitude, and ϕ_0 is the initial phase. Furthermore, the natural period of the oscillation is

$$T = \frac{2\pi}{\omega_0} = 2\pi \sqrt{\frac{M}{k_1 + k_2}} \quad (4)$$

However, when the mass of the springs cannot be neglected, we have to consider the effective mass. The effective mass of the oscillator is the sum of the effective mass of the spring and the mass of the object. Then, the angular frequency of the system becomes

$$\omega_0 = \sqrt{\frac{k_1 + k_2}{M + m_0}} \quad (5)$$

where m_0 is the effective mass of the spring. It is just one third of the spring's actual mass.

Then we study the mechanical energy in harmonic oscillations. The mechanical energy is composed of potential energy $U = kx^2/2$ and kinetic energy $K = mv^2/2$. By the conservation law of mechanical energy, the maximum kinetic energy K_{\max} is equal to the maximum potential energy U_{\max} when the object is at the maximum displacement $x = 0$ at equilibrium and $x = \pm A$ where $v = 0$ respectively. Hence,

$$k = \frac{mv_{\max}^2}{A^2} \quad (6)$$

2 Experimental setup

Generally, the measurement device includes springs, masses, electronic balance, electronic timer, air track, and Jolly balance. The Jolly balance consists of the following components from top to bottom: sliding bar with metric scale, vernier, small mirror with a horizontal middle line, fixed tube also with a horizontal middle line, know, and spring attached to the top of the sliding bar, shown in Figure 2.




Figure 2. Jolly balance.

To prepare for the measurement of the spring constant, we first need to place the small mirror in the fixed glass tube and coincide the line on the mirror, the line on the tube, and its reflection by adjusting the knob with no weight on the bottom end of the spring. We record the scale reading L_1 .

Then, on the bottom end of the spring we add mass m and adjust the knob to make the three lines coincide again and get the reading on scale as L_2 . Hence, we can find the spring constant as

$$k = \frac{mg}{L_2 - L_1} \quad (7)$$

After measuring L_2 and L_1 for several times with different masses m , we can do a linear fit with the least squares method to find a better estimation of the spring constant.




Figure 3. The experimental setup.

For the photoelectric measuring system shown in Figure 3, there are two parts: an electronic timer and two photoelectric gates. The shutter can be placed to cover the light emitted from the top so that the electronic timer can receive a signal.




Figure 4 The U-shaped shutter

Figure 4. The U-shape sutter.

When measuring the period, we use I-shaped shutters. However, for speed measurements, we use U-shape shutters that the signals are sent twice for every pass through, which is shown in Figure 4. We can read the time interval Δt from the recording on the timer and the distance $\Delta x = \frac{1}{2}(x_{in} + x_{out})$ between two signals. Hence, we can calculate the speed of the object when passing through the gate as $v = \Delta x / \Delta t$.

The apparatus is listed in Table 1, including measuring instruments together with their parameters.

Instruments	Quantity Measured	Range	Precision
Electronic Scale	Mass	6000 [g]	± 0.01 [g]
Metric Scale on the Air Track	Amplitude	N/A	± 0.01 [cm]
Electronic Timer	Time interval	N/A	± 0.0001 [s] (T) & ± 0.00001 [s] (S_2)
Caliper	x_{in} and x_{out}	150 [mm]	± 0.02 [mm]

Table 1. Experimental setup.

3 Measurement

3.1 Spring Constant

We first set the Jolly balance to be vertical and attach the spring as is shown in the experimental setup. Then we add a 20 g preload and adjust the knob I_1 and I_2 so that the mirror can move freely. Then check if the balance is parallel to the spring. If not, adjust knobs from. During the adjustment, we look at the Jolly balance from two orthogonal directions to make sure that the balance coincides with the spring.

Then, we adjust knob on the bottom G to coincide the three lines in the tube, set and record the initial position L_0 within 5.0–10.0 cm on the scale. Next, we add mass m_1 and record another position L_1 .

After that, we keep adding masses and measuring the positions for six times and record the corresponding order of the six masses. After recording, we calculate the spring constant k_1 by the least squares method.

Then, we replace spring 1 with spring 2 and repeat the steps above to calculate k_2 . After that, we take down the preload and repeat the steps above for the series of spring 1 and spring 2 to calculate k_3 . Finally, we compare the experimental value with the theoretical value.

3.2 Relation Between the Oscillation Period T and the Mass of the Oscillator M

(a) Adjust the air track so that it is horizontal.

First, we adjust the air track to be horizontal without anything on before turning on the air pump to protect the air track. After we turn on the air pump, we check whether there are any holes on the air track blocked. If there are any blocked holes, we would call the instructor.

Then, we place the cart on the air track still and adjust the single knob on it until the object can move freely back and forth in both directions.

(b) Horizontal air track

In a horizontal air track, we attach the two springs to both sides of the cart and set the I-shape shutter on it with the photoelectric gate at the equilibrium position.

First we add mass m_1 and release the cart in one direction and it oscillates about the photoelectric gate. The releasing position is about 5 cm. We release the cart with a caliper. Then, we set the timer to the "T" mode that the timer will record the time of ten oscillation periods automatically and record the period and the mass of the oscillator.

Then, we add masses to the object and repeat releasing the cart and recording the measurements for 5 times. After recording, we analyze the relationship between the period T and the mass M from the graph.

(c) Inclined air track

To control the inclination of the air track, we place every three of the plastic plates under the air track increased each time. We repeat doing measurements in (b) for two different inclinations with 3 and 6 plastic plates laid. After recording, we analyze the relationship between the period T and the mass M from the graph.

3.3 Relation Between the Oscillation Period T and the Amplitude A

We first keep original number of masses on the cart and change the amplitude for six times, such as 5.0/10.0/15.0/.../30.0 cm. We can then apply linear fit to the measurements and discuss the relationship between the amplitude A and the period T with correlation coefficient γ .

3.4 Relation Between the Maximum Speed and the Amplitude

We first measure the outer and inner distance of the U-shape shutter as x_{out} and x_{in} respectively by a caliper. We can get the distance $\Delta x = (x_{\text{out}} + x_{\text{in}})/2$. Then we use U-shape instead of I-shape shutter. We set the timer into the mode " S_2 " and oscillate the cart. After that, we record the readings of the time interval Δt when the two subsequent readings have the same digits to the left of the decimal point.

We change the amplitude for six times again like about 5.0/10.0/15.0/.../30.0 cm. Finally, we can obtain the maximum speed v_{max} for different amplitude A and then the spring constant. We can compare the spring constant k to that of the first part of the experiment.

3.5 Mass measurement

First we adjust the electronic balance whenever we use it so that the level bubble is in the circular center. Then, we gradually add masses according to the previously recorded order. After that, we measure the cart with the U-shape and the I-shape shutter respectively and the mass of spring 1 and spring 2. Finally, we record the measurements after the display on the scale vanishes.

4 Results and Calculations

4.1 Spring Constant

In this experiment, we measure L for spring 1, spring 2, and their series. The results are shown in Table 2.

spring 1 [cm] ± 0.01 [cm]		spring 2 [cm] ± 0.01 [cm]		series [cm] ± 0.01 [cm]	
L_0	5.21	L_0	3.13	L_0	5.80
L_1	7.28	L_1	5.04	L_1	9.68
L_2	9.31	L_2	6.93	L_2	13.51
L_3	11.18	L_3	8.97	L_3	17.55
L_4	13.20	L_4	10.90	L_4	21.51
L_5	15.14	L_5	12.73	L_5	25.51
L_6	17.25	L_6	14.81	L_6	29.46

Table 2. Spring constant measurement data.

Besides, we measure the weight added and the results are shown in Table 3.

m [g] ± 0.01 [g]	
1	4.72
2	9.49
3	14.19
4	18.84
5	23.68
6	28.44

Table 3. Weight measurement data.

We take the gravitational acceleration g as 9.794 m/s^2 , we can derive the Δl and mg for spring 1 in Table 4.

Measurement	Δl [m] ± 0.00014 [m]	mg [N] ± 0.0001 [N]
1	0.0207	0.0462
2	0.0410	0.0929
3	0.0597	0.1390
4	0.0799	0.1845
5	0.0993	0.2319
6	0.1204	0.2785

Table 4. Δl and mg for spring 1.

We can plot a graph of linear fit for mg vs. Δl .




Figure 5. mg v.s. Δl for spring 1.

The value of the spring constant can be found from the graph mg vs. Δl in Figure 5. From a linear fit to $mg = \alpha \Delta l + \beta$ we have the slope $\alpha = 2.34104$ N/m and the intercept $\beta = -0.00207$ N with standard errors $u_\alpha = 0.01564$ N/m and $u_\beta = 0.00122$ N and $R^2 = 0.99982$. By Eq. (7), the spring constant

$$k_1 = \alpha = (2.34 \pm 0.04) \text{ N/m}$$

with the uncertainty equal to the CI Half-Width

$$u_{k_1} = 0.04 \text{ N/m}$$

and relative uncertainty 1.7%. Analogously, for spring 2,

Measurement	Δl [m] ± 0.00014 [m]	mg [N] ± 0.0001 [N]
1	0.0191	0.0462
2	0.0380	0.0929
3	0.0584	0.1390
4	0.0777	0.1845
5	0.0960	0.2319
6	0.1168	0.2785

Table 5. Δl and mg for spring 2.

We can plot a graph of linear fit for mg vs. Δl .




Figure 6. mg v.s. Δl for spring 2.

The value of the spring constant can be found from the graph mg vs. Δl in Figure 6. From a linear fit to $mg = \alpha \Delta l + \beta$ we have the slope $\alpha = 2.38139$ N/m and the intercept $\beta = 0.00105$ N with standard errors $u_\alpha = 0.02067$ N/m and $u_\beta = 0.00156$ N and $R^2 = 0.9997$. By Eq. (7), the spring constant

$$k_2 = \alpha = (2.38 \pm 0.06) \text{ N/m}$$

with the uncertainty equal to the CI Half-Width

$$u_{k_2} = 0.06 \text{ N/m}$$

and relative uncertainty 3%. Analogously, for the series of spring 1 and spring 2,

Measurement	Δl [m] ± 0.00014 [m]	mg [N] ± 0.0001 [N]
1	0.0388	0.0462
2	0.0771	0.0929
3	0.1175	0.1390
4	0.1571	0.1845
5	0.1971	0.2319
6	0.2366	0.2785

Table 6. Δl and mg for series.

We can plot a graph of linear fit for mg vs. Δl .




Figure 7. mg v.s. Δl for series.

The value of the spring constant can be found from the graph mg vs. Δl in Figure 6. From a linear fit to $mg = \alpha \Delta l + \beta$ we have the slope $\alpha = 1.16951$ N/m and the intercept $\beta = 0.00154$ N with standard errors $u_\alpha = 0.00492$ N/m and $u_\beta = 7.54061 \times 10^{-4}$ N and $R^2 = 0.99993$. By Eq. (7), the spring constant

$$k_{1,2} = \alpha = (1.170 \pm 0.014) \text{ N/m}$$

with the uncertainty equal to the CI Half-Width

$$u_{k_{1,2}} = 0.014 \text{ N/m}$$

and relative uncertainty 1.2%.

4.2 Relation Between the Oscillation Period T and the Mass of the Oscillator M

The data of measurements for the period and the mass is shown in Table 7.

ten periods [ms] ± 0.1 [ms]					
horizontal		incline 1		incline 2	
m_1	12442.2	m_1	12447.4	m_1	12455.9
m_2	12602.0	m_2	12611.7	m_2	12610.2
m_3	12754.3	m_3	12760.3	m_3	12766.6
m_4	12913.8	m_4	12913.6	m_4	12923.3
m_5	13065.6	m_5	13072.6	m_5	13075.7
m_6	13224.6	m_6	13227.7	m_6	13231.9

Table 7. Measurement data for the T vs. M relation.

The mass of the oscillator M is equal to the equivalent mass of I-shape shutter plus the mass m_i . The equivalent mass $M_0 = m_{\text{obj}} + \frac{1}{3}m_{\text{spr1\&2}}$. For I-shape it is $181.82 \text{ g} = 0.18182 \text{ kg}$. Hence, we can calculate T^2 and M and derive Table 8.

Measurement	$T^2 \text{ [s}^2] \pm 0.00003 \text{ [s}^2]$			$M \text{ [kg]} \pm 0.00001 \text{ [kg]}$
	Horizontal	Incline 1	Incline 2	
1	1.54808	1.54938	1.55149	0.18654
2	1.58810	1.59055	1.59017	0.19131
3	1.62672	1.62825	1.62986	0.19601
4	1.66766	1.66761	1.67012	0.20066
5	1.70710	1.70893	1.70974	0.20550
6	1.74890	1.74972	1.75083	0.21026

Table 8. The relationship between the mass M and the period's square T^2 .

Hence, we can do linear fit for M vs. T^2 for three different inclinations. For the horizontal air track, the graph is Figure 8.




Figure 8. M vs. T^2 for horizontal inclination.

Alternatively, the linear fit of M vs. T^2 is given by equation $M = \alpha T^2 + \beta$. From the graph we know that the slope $\alpha = 0.11826 \text{ kg/s}^2$, the intercept $\beta = 0.00351 \text{ kg}$, the uncertainty of the slope $u_{k_h} = 0.002 \text{ kg/s}^2$. The Pearson's r is equal to 0.99995 that is very close to 1, so M and T^2 have a strong linear relationship.

For Inclination 1, the graph is Figure 9.




Figure 9. M vs. T^2 for Inclination 1.

Alternatively, the linear fit of M vs. T^2 is given by equation $M = \alpha T^2 + \beta$. From the graph we know that the slope $\alpha = 0.11875 \text{ kg/s}^2$, the intercept $\beta = 0.00255 \text{ kg}$, the uncertainty of the slope $u_{k_{T1}} = 0.002 \text{ kg/s}^2$. The Pearson's r is equal to 0.99995 that is very close to 1, so M and T^2 have a strong linear relationship. For Inclination 2, the graph is Figure 10.




Figure 10. M vs. T^2 for Inclination 2.

Alternatively, the linear fit of M vs. T^2 is given by equation $M = \alpha T^2 + \beta$. From the graph we know that the slope $\alpha = 0.1188 \text{ kg/s}^2$, the intercept $\beta = 0.00231 \text{ kg}$, the uncertainty of the slope $u_{k_{T^2}} = 0.001 \text{ kg/s}^2$. The Pearson's r is equal to 0.99996 that is very close to 1, so M and T^2 have a strong linear relationship.

4.3 Relation Between the Oscillation Period T and the Mass of the Oscillator M

From Section 3.3 we have measurements data for the maximum speed and the amplitude shown in Table 9.

A [cm] ± 0.1 [cm]	ten periods [ms] ± 0.1 [ms]
1 5.0	12281.6
2 8.0	12285.8
3 11.0	12283.9
4 14.0	12285.9
5 17.0	12288.1
6 20.0	12288.3

Table 9. Data for the T vs. A relation.

To study the relationship between T and A , we still try to plot a linear fit as is shown in Figure 11.




Figure 11. The Relationship between T and A .

The linear fit of M vs. T is given by equation $M = \alpha T + \beta$. From the graph we know that the slope $\alpha = 4.0381 \times 10^{-5}$ s/m, the intercept $\beta = 1.22806$ s, the uncertainty of the slope $u_{k_A} = 2.90095 \times 10^{-5}$ s/m. The Pearson's r is equal to 0.88813 that is smaller than 0.9, so M and T do not have a linear relationship.

4.4 Relation Between the Maximum Speed and the Amplitude

From Section 3.4 we have measurements data for the maximum speed and the amplitude shown in Table 10.

	A [cm] ± 0.1 [cm]	Δt [ms] ± 0.01 [ms]
1	5.0	39.65
2	10.0	19.62
3	15.0	13.13
4	20.0	9.85
5	25.0	7.86
6	30.0	6.70

Table 10. Data for the v_{max}^2 vs. A^2 relation.

x_{in} [mm] \pm 0.02 [mm]	x_{out} [mm] \pm 0.02 [mm]
4.82	15.10
4.84	15.08
4.82	15.10

Table 11. Measurement data for x_{in} and x_{out} .

Then the average value of x_{in} , x_{out} , and the distance Δx are

$$\bar{x}_{in} = \frac{1}{3} \sum_{i=1}^3 x_{in_i} = 0.00483 \pm 0.00002 \text{ m}$$

$$\bar{x}_{out} = \frac{1}{3} \sum_{i=1}^3 x_{out_i} = 0.01509 \pm 0.00002 \text{ m}$$

$$\Delta x = \frac{x_{in} + x_{out}}{2} = 0.00996 \pm 0.00002 \text{ m}$$

According to Eq. (6), we know that $mv_{max}^2 = (k_1 + k_2)A^2$, which indicates a linear relationship between mv_{max} and A . We calculate mv_{max} and A^2 in Table 12.

Measurement	mv_{max}^2 [kg · m ² /s ²]	$u_{mv_{max}^2}$ [kg · m ² /s ²]	A^2 [m ²]	u_{A^2} [m ²]
1	0.0115	0.00005	0.0025	0.0001
2	0.0469	0.0001	0.0100	0.0002
3	0.105	0.0004	0.0225	0.0003
4	0.186	0.0007	0.0400	0.0004
5	0.292	0.0012	0.0625	0.0005
6	0.402	0.0016	0.0900	0.0006

Table 12. The relationship between v_{max}^2 and A^2 .

According to the data in Table 12, we can plot the linear fit of v_{max}^2 vs. A^2 as shown in Figure 12.




Figure 12. The linear fit of v_{max}^2 vs. A^2 .

The linear fit of M vs. T^2 is given by equation $M = \alpha T^2 + \beta$. From the graph we know that the spring constant also the slope $\alpha = 4.6177 \text{ [kg} \cdot \text{m}^2/\text{s}^2]$, the intercept $\beta = -2.17481 \times 10^{-5} \text{ kg/s}^2$, the uncertainty of the slope $u_{k_M} = 0.13 \text{ kg/s}^2$. The Pearson's r is equal to 0.99979, very close to 1. Hence, we can deduce that mv_{max}^2 vs. A^2 has a linear relationship.

4.5 Mass Measurement Data

In the end of the exercise, we measure a set of masses that involve in calculation shown in Table 13. Note that

$$M_0 = m_{obj} + \frac{1}{3} m_{spr1\&2}$$

Measurement	$m \text{ [kg]} \pm 0.00001 \text{ [kg]}$
object with I-shape m_{obj}	0.17457
object with U-shape m_{obj}	0.17549
mass of springs 1 & 2 $m_{spr1\&2}$	0.02175
equivalent mass with I-shape M_{0I}	0.18182
equivalent mass with U-shape M_{0U}	0.18274

Table 13. Mass measurement data.

5 Conclusions and Discussion

In this experiment, we test the spring constants of two springs and their series. The results are

$$k_1 = (2.34 \pm 0.04) \text{ N/m}$$

$$k_2 = (2.38 \pm 0.06) \text{ N/m}$$

$$k_{1,2} = (1.170 \pm 0.014) \text{ N/m}$$

Since the two springs are in series, we want to show that they satisfy the law of series of springs.

$$k_s = \frac{k_1 k_2}{k_1 + k_2} = 1.180 \text{ N/m}$$

We check the relative error between $k_{1,2}$ and k_s by $\frac{|k_{1,2} - k_s|}{k_s}$,

$$error = \frac{|1.180 - 1.170|}{1.180} \times 100\% = 0.85\%$$

The relative error is small enough that the series is within the limit of Hooke's Law.

When we want to show the linear relationship between M and T^2 , we measure three spring constants k_h , k_{I1} , and k_{I2} . Using Eq. (4), the slope in the linear fit

$$\alpha = \frac{k_1 + k_2}{4\pi^2} = 0.11956 \text{ N/m}$$

Then the relative errors with different inclinations are

$$error_h = \frac{|0.11826 - 0.11956|}{0.11956} \times 100\% = 13.6\%$$

$$error_{I1} = \frac{|0.11875 - 0.11956|}{0.11956} \times 100\% = 8.47\%$$

$$error_{I2} = \frac{|0.11880 - 0.11956|}{0.11956} \times 100\% = 7.95\%$$

These relative errors vary from the theorital values, so the support of the linear relationship between M and T^2 need further explained. When adjusting the air track, the air flow blown from holes on the air track is weaker than that on the other one, so there may be considerable friction. Besides, we find that all the three experimental values are lower than the theoretical value, which indicates tha the two springs are not attached as a series perfectly. For example, one end is attached on the rubber band fixed on one end of the air track forms an inclination from the horizontal plane.

When we want to show that the period T and the amplitude A have no linear relationship. The Pearson's r turns out to be 0.88813 much smaller than 1 compared with moth linear fittings, so we can conclude that they are not related linearly.

When we want to show the linera relationship between the square of the maximum speed v_{max}^2 and the amplitude A , by Eq. (6),

$$\alpha = k_E = (4.62 \pm 0.13) \text{ kg/s}^2$$

Theoretically,

$$k_t = k_1 + k_2 = 4.72 \text{ N/m}$$

Hence, the relative error is

$$error = \frac{|4.72 - 4.62|}{4.72} 100\% = 2.12\%.$$

which is in a reasonable range but not very small, possibly due to the difference between the instantaneous speed and the average speed passing through the photoelectric gate.

In addition, when the amplitude is too large, the damping effect is very obvious, probably due to the dissipation inner the spring, even out of the limit of Hooke's Law. When installing the shutters on the air track, it is important to make sure that the photoelectric gate only detect one light block during a half period. The metal plate on the masses and ends of shutters can interfere the detection so that the displayed period is a half of the real period.

To improve the accuracy of this experiment, I would like to suggest that change the way to screw the shutters and the light source on the to avoid slipping back and forth. Fixing these experimental equipment can reduce errors.

A Measurement uncertainty analysis

A.1 Uncertainty of period measurements

The period measurements are single measurements with type-B uncertainty of 0.0001 s for $10T$. For one period, the uncertainty $u_T = 0.000001$ s.

A.2 Uncertainty of measurements for the time interval

The measurements for the time interval Δt are single measurements with type-B uncertainty of 0.00001 s. The uncertainty $u_{\Delta t} = 0.00001$ s.

A.3 Uncertainty of distance measurements

The distance measurements are single measurements with type-B uncertainty of 0.0001 m. The uncertainty $u_L = 0.0001$ m.

A.4 Uncertainty of measurements for the difference between the stretched position and the initial position

The uncertainty of the measurements for the difference between the stretched position and the initial position $\Delta l_i = L_i - L_0$ can be calculated from the uncertainty of the distance measurements u_L that

$$u_{\Delta l} = \sqrt{u_L^2 + u_L^2} = 0.00014 \text{ m}$$

A.5 Uncertainty of measurements of x_{in} and x_{out}

We have the type-B uncertainties of x_{in} and x_{out} $\Delta_{B,in} = \Delta_{B,out} = 2 \times 10^{-5}$ m. Then, the type-A uncertainties

$$\Delta_{A,in} = \frac{t_{0.95}}{\sqrt{3}} \sigma_x = \frac{t_{0.95}}{\sqrt{3}} \sqrt{\frac{\sum_{i=1}^3 (\bar{x} - x_i)^2}{3-1}} = 2.135 \times 10^{-5} \text{ m}$$

$$\Delta_{A,out} = \frac{t_{0.95}}{\sqrt{3}} \sigma_x = \frac{t_{0.95}}{\sqrt{3}} \sqrt{\frac{\sum_{i=1}^3 (\bar{x} - x_i)^2}{3-1}} = 2.135 \times 10^{-5} \text{ m}$$

Since $u_x = \sqrt{\Delta_A^2 + \Delta_B^2}$, we can calculate the uncertainty

$$u_{x_{in}} = \sqrt{(2.135 \times 10^{-5})^2 + (2 \times 10^{-5})^2} \text{ m} = 2.925 \times 10^{-5} \text{ m} \approx 0.00003 \text{ m}$$

$$u_{x_{out}} = \sqrt{(2.135 \times 10^{-5})^2 + (2 \times 10^{-5})^2} \text{ m} = 2.925 \times 10^{-5} \text{ m} \approx 0.00003 \text{ m}$$

A.6 Uncertainty of mv_{max}^2

Since we have $u_{x_{in}} = u_{x_{out}} = 0.00003$ m, the uncertainty of the distance Δx is

$$u_{\Delta x} = \frac{\sqrt{u_{x_{in}}^2 + u_{x_{out}}^2}}{2} = 0.00002 \text{ m}$$

Since if $F = \frac{X}{Y}$ the uncertainty propagation $u_r = \sqrt{u_{rX}^2 + u_{rY}^2}$,

$$u_{v_{max}} = v_{max} \sqrt{\frac{u_{\Delta x}^2}{\Delta x^2} + \frac{u_{\Delta t}^2}{\Delta t^2}}$$

Hence, we can calculate the uncertainty of the maximum speed:

Measurement	Δt [s] ± 0.00001 [s]	$u_{v_{max}}$ [m/s]
1	0.03965	0.0005
2	0.01962	0.0010
3	0.01313	0.0015
4	0.00985	0.0020
5	0.00786	0.003
6	0.0067	0.003

Based on that, we can calculate the uncertainty of mv_{max}^2 by

$$u_{mv_{max}^2} = mv_{max}^2 \sqrt{\frac{u_m^2}{m^2} + \frac{(2v_{max}u_{v_{max}})^2}{(v_{max}^2)^2}}$$

We list the uncertainty using the formula above,

Measurement	v_{max} [m/s]	$u_{v_{max}}$ [m/s]	$u_{mv_{max}^2}$ [kg · m ² /s ²]
1	0.251	0.0005	0.00005
2	0.508	0.0010	0.00019
3	0.759	0.0015	0.0004
4	1.011	0.002	0.0007
5	1.267	0.003	0.0012
6	1.487	0.003	0.0016

Table 14. The Uncertainty of mv_{max}^2 .

A.7 Uncertainty of T^2

By the uncertainty propagation formula, the uncertainty of T^2 is

$$u_{T^2} = 2Tu_T$$

where $u_T = 0.00001$ s. Using the formula above, we calculate the uncertainties of T^2 for each T measured in the experiment.

Horizontal		Inclination 1		Inclination 2	
T [s]	± 0.00001 [s]	u_{T^2} [s ²]	T [s]	± 0.00001 [s]	u_{T^2} [s ²]
1.54808		0.00003	1.54938		0.00003
1.58810		0.00003	1.59055		0.00003
1.62672		0.00003	1.62825		0.00003
1.66766		0.00003	1.66761		0.00003
1.70710		0.00003	1.70893		0.00003
1.74890		0.00003	1.74972		0.00003

Table 15. The uncertainty of T^2 for different inclinations.

Measurement	T [s] ± 0.00001 [s]	u_{T^2} [s ²]
1	1.22816	0.00002
2	1.22858	0.00002
3	1.22839	0.00002
4	1.22859	0.00002
5	1.22881	0.00002
6	1.22883	0.00002

Table 16. The uncertainty of T^2 for different amplitudes.

A.8 Uncertainty of A^2

Similar to the uncertainty of the square of the period, we have the uncertainty of the square of the amplitude

$$u_{A^2} = 2Au_A$$

where $u_A = 0.001$ m, we calculate a set of uncertainties of A^2 in section 4.4 in Table 17.

Measurement	A [m] ± 0.001 [m]	u_A^2 [m ²]
1	0.050	0.0001
2	0.100	0.0002
3	0.150	0.0003
4	0.200	0.0004
5	0.250	0.0005
6	0.300	0.0006

A.9 Uncertainty of the slope of the linear fit of mg vs. Δl

The uncertainty of the slope of the linear fit of mg vs. Δl is equal to the CI Half-Width.

For spring 1,

$$u_{k1} = 0.04 \text{ N/m}$$

with relative uncertainty

$$u_{k1,r} = \frac{u_{k1}}{k_1} = 1.7\%.$$

For spring 2,

$$u_{k2} = 0.06 \text{ N/m}$$

with relative uncertainty

$$u_{k2,r} = \frac{u_{k2}}{k_2} \times 100\% = 3\%.$$

For a series of spring 1 and spring 2,

$$u_{k3} = 0.014 \text{ N/m}$$

with relative uncertainty

$$u_{k3,r} = \frac{u_{k3}}{k_{1,2}} \times 100\% = 1.2\%.$$

A.10 Uncertainty of the slope of the linear fit of M vs. T^2

The uncertainty of the slope of the linear fit of M vs. T^2 is equal to the CI Half-Width.

For horizontal motion,

$$u_{k1} = 0.002 \text{ N/m}$$

with relative uncertainty

$$u_{k4,r} = \frac{u_{k4}}{k_4} = 1.7\%.$$

For Inclination 1,

$$u_{k5} = 0.002 \text{ N/m}$$

with relative uncertainty

$$u_{k5,r} = \frac{u_{k5}}{k_5} \times 100\% = 1.7\%.$$

For Inclination 2,

$$u_{k3} = 0.001 \text{ N/m}$$

with relative uncertainty

$$u_{k6,r} = \frac{u_{k6}}{k_6} \times 100\% = 0.8\%.$$

A.11 Uncertainty of the slope of the linear fit of T vs. A

The uncertainty of the slope of the linear fit of T vs. A is equal to the CI Half-Width.

$$u_{\alpha} = 3 \text{ s/m}$$

with relative uncertainty

$$u_{\alpha,r} = \frac{u_{\alpha}}{\alpha} = 72\%.$$

A.12 Uncertainty of the slope of the linear fit of mv_{max}^2 vs. A^2

The uncertainty of the slope of the linear fit of T vs. A is equal to the CI Half-Width.

$$u_{\alpha} = 0.13 \text{ s/m}$$

with relative uncertainty

$$u_{\alpha,r} = \frac{u_{\alpha}}{\alpha} = 2.8\%.$$

B Data Sheet

UM-SJTU JOINT INSTITUTE
PHYSICS LABORATORY
DATA SHEET (EXERCISE 3)

Name: 刘明华 Student ID: 5621910996
Name: 席广源 Student ID: 518021910778
Group: 9 Date: July 16, 2019

NOTICE. Please remember to show the data sheet to your instructor before leaving the laboratory. The data sheet will not be accepted if the data are recorded with a pencil or modified with a correction fluid/tape. If a mistake is made in recording a datum item, cancel the wrong value by drawing a fine line through it, record the correct value legibly, and ask your instructor to confirm the correction. Please remember to take a record of the precision of the instruments used. You are required to hand in the original data with your lab report, so please keep the data sheet properly.

spring 1 $(\text{N}) \pm 0.11 \text{ (N)}$	spring 2 $(\text{N}) \pm 0.01 \text{ (N)}$	series $(\text{N}) \pm 0.01 \text{ (N)}$
L_0 5.21	L_0 3.12	L_0 5.80
L_1 7.28	L_1 5.04	L_1 9.68
L_2 9.31	L_2 6.93	L_2 13.51
L_3 11.19	L_3 8.86 8.97	L_3 17.55
L_4 13.20	L_4 10.72 10.92	L_4 21.51
L_5 15.14	L_5 12.73 12.83	L_5 25.51
L_6 17.25	L_6 14.81	L_6 29.46

Table 1. Spring constant measurement data.

Instructor's signature: Martin

horizontal		ten periods	Δt	\pm	Δt	\pm	Δt
		incline 1				incline 2	
m_1	1.447 1244.2	m_1	1244.4			m_1	1245.9
m_2	1.447 1244.9	m_2	1261.7			m_2	1261.2
m_3	1.447 1275.3	m_3	1276.3			m_3	1276.6
m_4	1.447 1291.8	m_4	1291.3			m_4	1291.3
m_5	1.447 1308.6	m_5	1307.6			m_5	1307.5
m_6	1.447 1325.6	m_6	1325.6 1327.7			m_6	1327.9


Table 2. Measurement data for the T vs. M relation.

A	Δt	ten periods	Δt	\pm	Δt
1	5.0	1.281 1281.6			
2	8.0	1228.8			
3	11.0	1223.7			
4	14.0	1228.9			
5	17.0	1228.1			
6	20.0	1228.3			

Table 3. Data for the T vs. A relation.

A	Δt	Δt	\pm	Δt
1	5.0	39.6		
2	8.0	19.2		
3	11.0	15.1		
4	20.0	9.8		
5	25.0	7.8		
6	30.0	6.7		
x_{in}	Δt	x_{out}	Δt	\pm
1.5 1.5	1.5	1.5		
1.5	1.5	1.5		
1.5	1.5	1.5		

Table 4. Data for the v_{max}^2 vs. A^2 relation.

Instructor's signature: 

m	2 ± 0.01
1	1.72
2	1.72
3	1.72
4	1.72
5	1.72
6	1.72

Table 5. Weight measurement data.

object with I-shape m_{obj}	2 ± 0.01
object with U-shape m_{obj}	2 ± 0.01
mass of springs 1 & 2 $m_{spring 1 \& 2}$	2 ± 0.01
equivalent mass M_p	2 ± 0.01
I-shape	1.72
U-shape	1.72

Table 6. Mass measurement data.

Instructor's signature: _____